

Graphics Application Guide

and Warranty Information

READ THIS INFORMATION CAREFULLY

IMPORTANT: Printed graphics may have a clear laminate layer that extends about ½" beyond the edge of the graphic. Do NOT remove this clear protective layer. APPLY all full color decals with an overlamine clear lip DRY...

This sheet contains important information regarding your graphics. Your graphics are warranted for one (1) year from the time of purchase against delamination and significant visible fading. Vinyl graphics are similar to clothes: The manner in which the graphics are applied and cared for will determine their durability. The graphics should not be exposed to automatic car washes, power washers, solvents, petroleum-based products, or any other harsh conditions. The graphics should be hand-washed to preserve their beauty and durability. With reasonable care, your graphics can last up to three times the warranted period. For more information, please refer to the [Terms Of Service](#) agreement on our website.

One of the following boxes may be checked below. If so, this is merely a recommendation and may not necessarily be the best method for your particular situation:

- Dry application
- Wet or lightly wet application

Dry application is usually preferred, especially for smaller graphics (less than 1 square foot). However, wet application can be helpful on large graphics that are prone to bubbles or need repositioning before final application. Wet application is usually done by moistening the destination surface and/or the adhesive side of the vinyl with one of the following chemicals: Glass Plus™, very lightly soapy water, or auto windshield cleaner fluid. If you use a glass cleaner, make certain that it does not contain ammonia.

Some of your graphics may be covered with a sheet of tacky, light tan material that resembles masking tape. This is called "application tape" and is useful when positioning your graphics. You may use it (or completely remove it) at your own discretion.

If your graphics are covered with masking tape:

- 1) Clean your destination surface thoroughly. Determine how your graphics will be positioned and mark the corners (or tape down one edge to create a 'hinge').
- 2) Lay the graphics face down, exposing the white wax paper backing. Carefully peel the wax paper away, and make sure all your graphics stick to the application tape. Make sure nothing touches the graphics!
- 3) If you are applying wet, lightly mist the destination surface and/or the adhesive side of the graphics.
- 4) Position the graphics and the attached application tape where you want them. If you are applying wet, you can buy more time by re-wetting the surfaces before repositioning the graphics.
- 5) Using a squeegee or any other flat item (like a credit card), start from the middle and firmly press the air out from underneath the graphics. Make sure your strokes overlap so there are no bubbles or wrinkles.
- 6) Let the graphics set for a few minutes. There is no need to immediately remove the application tape.
- 7) Start on a top corner and carefully peel the application tape away from the graphics. Peel away at a sharp angle, in order to prevent the graphics from coming up and sticking to the application tape. If part of the graphic doesn't want to stick, try laying it back down, squeegeeing again, and waiting a little longer.
- 8) Allow the graphics to bond well before touching them, washing them, or exposing them to wind or rain. We recommend waiting 24 hours.

If your graphics are NOT covered with masking tape:

- 1) Clean your destination surface thoroughly.
- 2) Lay the graphics face down, exposing the wax paper backing. Carefully peel the wax paper away. Make sure nothing touches the graphics!
- 3) If you are applying wet, lightly mist the destination surface and/or the adhesive side of the graphics.
- 4) Position the graphics where you want them. If you are applying wet, you can buy more time by re-wetting the surfaces before repositioning the graphics.
- 5) Using a squeegee or any other flat item (like a credit card), start from the middle and firmly press the air out from underneath the graphics. Make sure your strokes overlap so there are no bubbles or wrinkles.
- 6) Allow the graphics to bond well before touching them, washing them, or exposing them to wind or rain. We recommend waiting 24 hours.

Graphics are designed for flat surfaces ONLY. Application to vehicle molding, bumpers, curves, corrugated surfaces, etc. will VOID YOUR WARRANTY IMMEDIATELY.